



RWY	BRG (T)	PCN	TORA (m)	TODA (m)	ASDA (m)	LDA (m)	PAPI / VASIS	THR COORDINATES	THR (ft)
08L	081°	PCN 120/F/A/X/T	3023	3023	3092	3023	P 3°	52°33.45845'N 013°15.94493'E	110
26R	261°	PCN 120/F/A/X/T	3023	3023	3091	3023	P 3°	52°33.71725'N 013°18.58543'E	117
08R	081°	PCN 120/F/A/W/T	2428	2428	2491	2324	P 3°	52°33.40958'N 013°16.59043'E	109
26L	261°	PCN 120/F/A/W/T	2428	2488	2476	2208	P 3°	52°33.58955'N 013°18.42732'E	122

Note:  
 - Pilots intending to use mil apron contact BERLIN MILITARY on 369.250 or 136.000 15 MIN prior to landing.

CHANGE: EDITORIAL

Seite absichtlich leer gelassen

Page intentionally left blank