

DESCRIPTION OF SID

<p>SB 1 (RWY 21)</p>	<ul style="list-style-type: none"> - Climb and turn left to intercept BUE R-205 prior passing BUE/4 DME, cross BUE/4 DME at 3000 ft - Cross BUE/10 DME at 4000 ft - Continue via SB 1 - 21
<p>SB 21 (RWY 03)</p>	<ul style="list-style-type: none"> - Climb straight ahead, pass BUE/5 DME at 4000 ft - Turn right to heading 228° to intercept BUE R-205 at BUE/10 DME - Cross BUE R-080 at 4000 ft - Continue via SB 1 - 21
<p>SB 1 - 21</p>	<ul style="list-style-type: none"> - Pass BUE R-205/10 DME at 4000 ft, BUE/29 DME and BUE/34 DME at FL 70 or above - At BUE R-205/34 DME turn left to intercept SPA R-178 - Pass SPA R-178/20 DME at FL 70 or above - Continue via TRANSITION

TRANSITIONS

<p>TOLEY</p>	<ul style="list-style-type: none"> - Maintain FL 70 - At SPA R-178/20 DME turn left to intercept RMS R-281 and proceed to TOLEY (RMS R-281/23 DME) - Cross TOLEY at FL 100 or below
<p>SB 1V - 21V</p>	<p>FOR VMC ON TOP</p> <ul style="list-style-type: none"> - Pass SPA R-178/25 DME at FL 95 or below
<p>SB 1 - 21 H/L</p>	<ul style="list-style-type: none"> - Pass SPA R-178/20 DME at FL 70 or above - Pass SPA R-178/23 DME and 28 DME at FL 70 or above - Pass SPA R-178/34 DME at FL 120 or below
<p>SB 1 - 21 H/L</p>	<p>(SB 1/21 Low)</p> <ul style="list-style-type: none"> - At SPA R-178/34 DME turn left tracking 110° - Cross PIREK at FL120 or below, cross GERKU at FL170 <p>(SB 1/21 High)</p> <ul style="list-style-type: none"> - At SPA 178/34 DME turn left tracking 110° - Cross PIREK at FL250 or above

CHANGE: EDITORIAL

AFSBw 03 JUL 2008