

DESCRIPTION OF SID

<p>SB 3 (RWY 21)</p>	<ul style="list-style-type: none"> <li>- Climb and turn left to intercept BUE R-205 prior passing BUE/4 DME, cross BUE/4 DME at 3000 ft</li> <li>- Pass BUE R205/10 DME at 4000 ft and BUE R-205/13 DME at 6000 ft or above</li> <li>- At BUE R-205/13 DME turn right to intercept SPA R-108 inbound</li> <li>- Cross SPA R-108/5 DME at FL 70 or above</li> <li>- At SPA R-108/3 DME turn right to intercept SPA R-010 outbound</li> <li>- Continue via SB 3 - 23</li> </ul>
<p>SB 23 (RWY 03)</p>	<ul style="list-style-type: none"> <li>- Climb on rwy heading to BUE/5 DME, pass BUE/5DME at 4000 ft</li> <li>- Turn right to heading 228°, cross BUE R-080 at 4000 ft</li> <li>- Intercept BUE R-205 at 9 DME, cross BUE/10 DME at 4000 ft</li> <li>- Pass BUE R-205/13 DME at 6000 ft or above and turn right to intercept SPA R-108 inbound, pass SPA R-108/5 DME at FL 70 or above</li> <li>- At SPA R-108/3 DME turn right to intercept SPA R-010 outbound</li> <li>- Continue via SB 3 -23</li> </ul>
<p>SB 3 -23</p>	<ul style="list-style-type: none"> <li>- Pass SPA R-010/30 DME at FL 140 or below</li> <li>- Continue via transitions</li> </ul>
<p>TRANSITIONS</p>	
<p>SB 3V - 23V</p>	<p>FOR VMC ON TOP</p> <ul style="list-style-type: none"> <li>- Pass SPA R-010/30 DME at FL95 or below</li> </ul>
<p>NOR</p>	<ul style="list-style-type: none"> <li>- Pass SPA R-010/30 DME at FL 140 or below</li> <li>- Pass REMGA (SPA R-010/32 DME) at FL 140 or above</li> <li>- At DEPUK (SPA R-010/48 DME) turn left to intercept NOR R-117 inbound</li> <li>- Pass NOR at FL250 or above</li> </ul>

CHANGE: EDITORIAL

AFSBw 03 JUL 2008